


POTTING BENCH



JENWOODHOUSE

MATERIALS:

- (2) 2 x 2 x 8 Ft. Boards
- (9) 1 x 3 x 8 Ft. Boards

TOOLS:

- Tape Measure
- Pencil

(6) 1 x 2 x 8 Ft. Boards

(1) Lattice

8 inches of a scrap 1 x 6 Board

2 ½-inch Simpson Strong-Tie® Stainless Steel Wood Screws

2-inch Simpson Strong-Tie® Stainless Steel Wood Screws

1 ¼-inch Simpson Strong-Tie® Stainless Steel Wood Screws

1 ¼-inch Brad Nails

1-inch Brad Nails

Exterior Wood Glue

Carpenter's Square

Drill

Circular Saw

Jigsaw

Brad Nailer or Hammer

Safety Glasses

Hearing Protection

Dust Mask

CUT LIST:

(2) 2x2 @ 42 inches (back legs)

(2) 2x2 @ 33 ¾ inches (front legs)

(12) 1x3 @ 42 inches (slats)

(4) 1x2 @ 42 inches (long aprons)

(4) 1x2 @ 17 ¼ inches (short aprons)

(4) 1x2 @ 17 ¼ inches (supports)

(4) 1x3 @ 18 ¾ inches (sides)

(2) 1x6 @ 4 inches (shelf brackets)

(2) 1x3 @ 45 inches (top shelf slats)


(3) 1x2 @ 5 ½ inches (top shelf slat supports)

(1) 1x3 @ 42 inches (lattice top rail)


(2) 1x2 @ 14 inches (lattice stiles)

(1) 1x2 @ 42 inches (lattice bottom rail)

(1) lattice @ 42 inches x 10 inches


**STEP 1 – BUILD THE TOP AND BOTTOM SHELF**

Measure, mark, and cut 1x3 slats and 1x2 aprons and supports to length. Pre-drill pilot holes and construct as shown with 1 1/4-inch wood screws and wood glue. Space slats 3/4 inches apart.




STEP 2 – CUT THE LEGS

Measure, mark, and cut 2x2 legs to length.

FIG. 3**STEP 3 – ATTACH THE TOP AND BOTTOM SHELVES**

Position top and bottom shelves as shown and attach to legs with 2-inch wood screws and wood glue.

FIG. 4**STEP 4 – ATTACH THE SIDES**

Measure, mark, and cut 1x3 sides to length and attach to legs with 1 ¼-inch wood screws and wood glue.




FIG. 5B**STEP 5 – CUT AND ATTACH THE SHELF BRACKETS**

Measure, mark, and cut shelf brackets as shown. Use a jigsaw to cut the curved parts. Attach the shelf brackets to the potting bench with 1 ¼-inch wood screws and wood glue.






FIG. 6B**STEP 6 - BUILD AND ATTACH THE TOP SHELF**

Measure, mark, and cut 1x3 and 1x2 boards to length. Construct as shown with 1 ¼-inch wood screws and wood glue. Space slats ¾ inches apart. Attach the shelf to the potting bench with 1 ¼-inch wood screws and wood glue.

FIG. 7



JENWOODHOUSE

STEP 7 – CUT AND ATTACH THE LATTICE

Measure, mark, and cut lattice to size. Cut 1x3 and 1x2 boards to length. Position lattice as shown and attach it to the potting bench with 1-inch brad nails and wood glue. Frame the lattice with the 1x3 and 1x2 boards as shown. Attach the frame with 1 ¼-inch brad nails and wood glue.

Sand, stain and/or paint, and finish with an exterior-grade finish.

Visit www.JenWoodhouse.com for more details and photos.